



LUX LES
DOM DEKOR

LUX LES Dom-Dekor wooden wall PANELS.
LUX LES Dom-Dekor wooden wall Peel&Stick PANELS.
LUX LES Dom-Dekor wooden FURNITURE and DECOR.

CARE and CLEANING

(1 page, Valid as of September 15, 2021)

Cleaning Wooden Wall Panels and Furniture:

- Besides being beautiful, our LUX LES Dom-Dekor wooden wall panels and furniture are virtually maintenance free. The primary method of cleaning is dusting normally with a clean, dry cloth. Keep in mind that traditional dusting sprays or furniture polishes won't work on non-porous surfaces, so don't use them. These products tend to simply sit on top of the surface, as they are never absorbed into the material, resulting in a residue that can detract from the panel's and furniture's appearance.
- As needed, or on a semi-regular basis, damp wipe your wall panels and furniture. Remember never to saturate the panels and furniture- use only slightly damp (thoroughly wrung out) cloths. Wipe from top to bottom, going with the grain to avoid visible streaks. Important: Do not use wax, ammonia-based cleansers, detergents, polishes, abrasive cleaners. These products contain chemicals that can cloud and/or permanently damage the finish of your wooden panels and wooden furniture.
- We recommend oiling the panels one time in two years to keep the look fresh.

Hanging Pictures and Other Wall Decor:

LUX LES Dom-Dekor wooden wall panels not load-bearing. For hanging pictures and other heavy objects such as televisions, mirrors or sizable artwork, drill clearance holes through the wall plank and mount objects directly to wall studs with screws or nails. Note that when decorating your wall, slight adjustments to cleaning the panels may be necessary. Hang objects wisely so that you can be thorough and adequately maintain the uniform appearance of your LUX LES Dom-Dekor wooden wall panels.

Sunlight:

It's a good idea to minimize the amount of direct sunlight on your panels and furniture to reduce any fading effects.

Our knowledgeable customer service team is here to help. Please contact us if you have any additional questions about how to clean your LUX LES Dom-Dekor wooden wall panels and furniture.

LUX LES Dom-Dekor, proizvodnja, trgovina in storitve, d.o.o.

Dragovanja vas 6A, 8343 Dragatuš, Republika Slovenija
matična številka: 8535574000, davčna številka: 90952367
IBAN SI56 0315 2100 0481 063, odprt pri SKB d.d

+386 40 844 057
office@luxles.si
www.luxles.si